
ASSEMBLY: AIREBAFFLE™ PLUS (AIRELIGHT™ ACOUSTIC SERIES)



PART LIST

DESCRIPTION	QTY
Airebaffle™ Plus	1
1/16" cable (5')	2
Hanging hardware adjustable	2
Hanging hardware upper deck	2





Airebaffle™ Plus Hanging Overview



1) Locate two threaded inserts on opposing sides of the Airebaffle $^{\text{TM}}$ Plus.



2) Attach adjustable hanging hardware(2) to these two threaded inserts.



1

ASSEMBLY: AIREBAFFLE™ PLUS (AIRELIGHT™ ACOUSTIC SERIES)







3) Mount upper deck hardware w/cable to ceiling.(Fig A) Insert cable into adjustable hanging hardware. Trim excess cable once desired height is set.



4) Remove mating male connector from input connector adjacent to hanging hardware.



5) Identify polarity on connector and insert power cabling from remote driver into male connector.



6) Connect power to Airebaffle connector.



2