# AIRELIGHT LINEAR2 SC 1.0 INSTALLATION INSTRUCTIONS



# **Airelight Pre Install Wiring Notes**

- Airelight Linear luminaires should only be connected to 24V Class II drivers. Use of any other power source will cause damage and may void the warranty.
- Only use 18 AWG stranded wire to connect directly to each luminaire. If larger gauge is used for cable drop, reduce to 18 AWG to each luminaire. Never use solid core wire when connecting to a luminaire.
- Goldeneye will not be held responsible if the luminaires are not installed according to applicable codes and safety standards.


- 1. Remove the junction box cover.
- 2. Make wiring connections from 24V power supply to first luminaire. (Reference cable length chart below)
- 3. Reattach junction box cover.

\*Recommended Cable Lengths to Minimize Voltage Drop


Watts		28.8	43.2	57.6	72	86.4
(ft)	(2')	(4')	(6')	(8')	(10')	(12')
18 AWG	64 ft	32 ft	21 ft	16 ft	13 ft	11 ft
16 AWG	102 ft	51 ft	34 ft	25 ft	20 ft	17 ft
14 AWG	161 ft	81 ft	54 ft	40 ft	32 ft	27 ft
12 AWG	257 ft	129 ft	86 ft	64 ft	51 ft	43 ft

AL2-1.0-SC/ES-xx-xx-xx = 7.2 Watts/ft

### Wiring Example #1: Airelight Linear2 1.0s spaced apart (greater than 2' end to end)



# Wiring Example #2: Airelight Linear2 1.0s mounted end to end (less than 2' end to end)



## EM BATTERY INSTALLATION INSTRUCTIONS (AIRELIGHT LINEAR2 SC 1.0)



# **Airelight Pre Install Wiring Notes**

- Airelight Linear luminaires should only be connected to 24V Class II drivers. Use of any other power source will cause damage and may void the warranty.
- Only use 18 AWG stranded wire to connect directly to each luminaire. If larger gauge is used for cable drop, reduce to 18 AWG to each luminaire. Never use solid core wire when connecting to a luminaire.
- Goldeneye will not be held responsible if the luminaires are not installed according to applicable codes and safety standards.


- 1. Remove the junction box cover.
- 2. Make wiring connections from 24V power supply to first luminaire. (Reference cable length chart below)
- 3. Reattach junction box cover.

\*Recommended Cable Lengths to Minimize Voltage Drop

Watts	14.4	28.8	43.2	57.6	72	86.4
(ft)	(2')	(4')	(6')	(8')	(10')	(12')
18 AWG	64 ft	32 ft	21 ft	16 ft	13 ft	11 ft
16 AWG	102 ft	51 ft	34 ft	25 ft	20 ft	17 ft
14 AWG	161 ft	81 ft	54 ft	40 ft	32 ft	27 ft
12 AWG	257 ft	129 ft	86 ft	64 ft	51 ft	43 ft

AL2-1.0-SC/ES-xx-xx-xx = 7.2 Watts/ft

#### Wiring Example #3: EM BATTERY (Airelight Linear2 1.0s spaced apart (greater than 2' end to end)



#### Wiring Example #4: EM BATTERY (Airelight Linear2 1.0s mounted end to end (less than 2' end to end)

